

1 FAULT-CODES AND APPLIANCE MESSAGES

1.1 Fault-Codes (ordered)

- Error 7 – 18
- Error 19 – 31
- Error 34 – 56
- Error 59 – 73

2 SERVICE-PROGRAMS

2.1 Customer service test program

- Activate test mode
- Select test program
- Start/Restart test program
- Abort test program
- Leave test mode

2.2 Stored error codes / Error search

- Activate error search mode
- Display of 1st error
- Display of 1st – 5th error
- Leave error search mode

3 FUNCTIONS OF SERVICE-PROGRAMS

3.1 Customer service test program

- 1 Automatic test
- 2 Fans test
- 3 Motor
- 4 Valves
- 5 Pump
- 6 Heater
- 7 Pressure sensor adjustment
- 9 Flow rate sensor
- 12 Heater (dryer)
- 13 Display

4 VARIANT CODING

4.1 Variant coding PU

- 2 Activate PU variant coding mode
- 3 Select variant used by PU
- 4 Leave PU variant coding mode
- 5 1 Setting machine device class
- 6 2 Setting speed variant
- 7 3 Setting Aqua stop / warm water variant
- 8 4 Setting water valve variant
- 9 5 Setting door lock variant
- 10 6 Setting flow sensor variant
- 11 7 Setting turbidity sensor variant
- 12 8 Setting 3D sensor variant
- 13 9 Setting foam wash sensor variant
- 14 10 Setting dosage system
- 15 11 Setting VT set






4.2 Variant coding OU

- 16 Activate OU variant coding mode
- 17 Select variant used by OU
- 18 Leave PU variant coding mode
- 19 1 Setting acoustic feedback
- 20 2 Setting brand
- 21 3 Setting child proof
- 22 4 Setting load display
- 23 5 Setting panel colour
- 24 6 Setting sales area
- 25 7 Setting overdosage
- 26 8 Setting key variant
- 27 9 Setting menu variant

17

17 Explanation:

- 17 Key w/o LED.....
- 17-18 Key with LED.....
- 18 Program selector.....
- 19 LED Start / Pause illuminate.....
- 20 LED Start / Pause is flashing.....
- 21 LED Start / Pause is off.....
- 21 Press key.....
- 21 Turn program selector to pos.9
- 22 while key is pressed.....
- 22-23 Leave key.....





1 FAULT CODES AND APPLIANCE MESSAGES

Display	Description	Possible Cause	Check / Remedial action / Remark
F.No Normal- Test mode	Possible effect		





1.1 Fault codes (in ascending order)

FATAL ERROR sequence:

- washing or drying program aborted
- door is locked possibly
- operator control actions are blocked
- display is frozen
- pump is activated possibly





7		E:07	Condensor outlet NTC error - FATAL ERROR without pumping	- Condenser outlet NTC broken or short circuit	- check condenser outlet NTC - and drying unit wire harness
8		E:08	Condensor inlet NTC error - FATAL ERROR	- Condenser inlet NTC broken or short circuit	- check condenser inlet NTC - and drying unit wire harness
9	E:09	E:09	Drying tunnel outlet NTC error - FATAL ERROR	- Drying tunnel outlet NTC broken or short circuit	- check drying tunnel outlet NTC - and drying unit wire harness
16		E:16	Door lock is not closed - washing program is halted - a restart is possible - error will not be stored	- door is open - door switch is not actuated	- close door - check door lock, check wire harness Normal mode: start any washing program with an open door
17		E:17	water filling time exceeded (conventional measurement) - washing program is halted - pump starts after 5 min - a restart is possible	- water tap is closed - water pressure <1bar at supply - filter or supply is blocked - solenoid valve / aqua stop valve is broken - pressure sensor is broken	- open water tap - check components, wire harness Pos. 7 Water level (Pressure sensor) Pos. 4 Valves
18	E:18	E:18	pumping time exceeded - FATAL ERROR without 90sec pumping	- pump is blocked or broken - pressure sensor is broken - hose to the pressure sensor is blocked - draining hose is blocked	- switch ON/OFF for reset - check components, wire harness Pos. 5 Pump

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		2 of 25




Display			Description Possible effect	Possible Cause	Check / Remedial action / Remark
F.No	Normal-	Test mode			
FATAL / REMANENT ERROR sequence:			- washing or drying program aborted - door is locked possibly - operator control actions are blocked	- display is frozen - pump is activated possibly	Reset REMANENT ERROR: "Safe state flag" must be set
19		E:19	heating time exceeded - washing program will be finished without heating	- heating circuit is broken - set temperature can not be achieved - low voltage - fossil heater or heater is broken - heater relay is blocked	- check heater - check wire harness - check control Pos. 6 Heater
20		E:20	unexpected heating - REMANENT ERROR	- NTC is broken (out of range) - heater relay is stuck - the heater is actuated in a non heating period	- reset remanent error (see instruction above) - check NTC, heater, replace power module Pos. 6 Heater
23	E:23	E:23	aqua stop actuated - washing program is aborted - the pump is actuated	- water in the base tub - leaky water system - aqua stop switch is blocked / broken	- check leak tightness of water system - check aqua stop switch, wire harness Normal mode
26		E:26	error of analogue pressure sensor (provides error voltage) - FATAL ERROR	- pressure sensor broken - hose to the pressure sensor is blocked	- switch ON/OFF for reset - check pressure sensor, wire harness Pos. 7 Water level (Pressure sensor)
28		E:28	error of flow sensor (provides implausible values) - The water intake is changed from volume based to time based	- flow sensor is broken	- check flow sensor - check wire harness Pos. 7 Water level (Pressure sensor)
29		E:29	no water filling detected by flow sensor (fast measurement) - washing program is halted - a restart is possible	- water tap is closed - water pressure <1bar at supply - filter is blocked / supply is blocked - valves or pressure sensor broken	- open water tap - check components, wire harness Pos. 7 Water level (Pressure sensor) Pos. 4 Valves
31		E:31	overflow level exceeded - pump is activated until water level < overflow level (at least 3 min) - the program is continued	- pump, draining hose is blocked, valve is stuck - adjustment of pressure sensor is incorrect └ pressure sensor is blocked └ hose to the pressure sensor is blocked	- check components, wire harness Pos. 7 Water level (Pressure sensor) Pos. 4 Valves Pos. 5 Pump

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		3 of 25







Display			Description Possible effect	Possible Cause	Check / Remedial action / Remark
F.No	Normal-	Test mode			
FATAL / REMANENT ERROR sequence:			- washing or drying program aborted - door is locked possibly - operator control actions are blocked	- display is frozen - pump is activated possibly	
34		E:34	Door lock can not be locked - washing program is aborted - door is unlocked possibly - operator control actions are blocked	- door lock is broken - door, or door hook is stuck - stiff gasket	- switch ON/OFF for reset - check door lock - check mechanic - check wire harness
35		E:35	Door lock can not be unlocked - FATAL ERROR without prgram abort and pumping	- door lock broken - Window clamp - gasket to inflexible	- switch ON/OFF for reset - check door lock, mechanism, and wire harness
37		E:37	Error of temperature sensor: break - washing program will be finished without heating	- NTC is broken	- check NTC, and wire harness Pos. 6 Heater
38		E:38	Error of temperature sensor: short-circuit - washing program will be finished without heating	- NTC is short-circuit	- check NTC, and wire harness Pos. 6 Heater
40		E:40	Error of mains frequency synchronisation - washing program is aborted	- weak power supply	- Check power supply Normal mode
42		E:42	Uncontrolled run up of drum motor - FATAL ERROR without 90sec pumping	- Speed sensor, control, or triac on control is broken - Motor is blocked, drum is blocked by laundry	- start test mode for reset - check control Pos. 3 Motor, normal mode
43		E:43	Locked rotor (for normal mode only in error stack and Last Error) - washing program is finished with limited motor running	- drum is blocked by laundry - motor is blocked	- switch ON/OFF for reset without laundry - check load, check motor Pos. 3 Motor
44		E:44	Test of reversing relay failed - FATAL ERROR without 90sec pumping	- control is broken - triac is broken	- start test mode for reset - check control Pos. 3 Motor, normal mode
56		E:56	Power unit & operating unit communication error Normal mode: - appliance is switched off after 60s, error is stored Test mode: FATAL ERROR (a)	- faulty D-Bus communication between PU and OU	- switch ON/OFF for reset - check wire harness between PU and OU

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		4 of 25



Display			Description	Possible Cause	Check / Remedial action / Remark
F.No	Normal-	Test mode	Possible effect		
FATAL / REMANENT ERROR sequence:			- washing or drying program aborted - door is locked possibly - operator control actions are blocked	- display is frozen - pump is activated possibly	
59		E:59	3D-Sensor: measurement error or plausibility error - reduced spin speed	- wire harness, control, or 3D-Sensor is broken - EMC failure - magnet not in position - software of 3D-Sensor is incompatible	- check wire harness, control, 3D-Sensor - check position of magnet Pos.3 Motor
61		E:61	Implausible door lock status - FATAL ERROR	- door is locked but open - emergency unlock was actuated by hand	- switch ON/OFF for reset - check door lock, mechanic, and wire harness Normal mode
63		E:63	System error - FATAL ERROR without 90sec pumping	- no communication between power-/operating unit - no communication between power-/drying module	- check D-Bus wire harness - replace power- or dryer module
67	E:67	E:67	Implausible or inexistent variant coding - FATAL ERROR without 90sec pumping	- incorrect or inconsistent variant coding on PU/OU - software of control is incompatible	- switch ON/OFF for reset - repeat variant coding - replace control(s) - reprogram the control(s) (development only) Variant coding
68		E:68	Magnetic door lock actuation not possible (according tocoil temperature "A:03") MINOR - error is stored in error stack only in normal mode	- temperature of the door lock coil is too high for actuation (lock or unlock)	- it is just a warning Normal mode
73		E:73	PU-DU communication - FATAL ERROR (c, d)	- wrong PU-DU communication	- replace control(s) - reprogram the control(s) (development only)



2 SERVICE PROGRAMS


Function	Actuation	Display	Remark
----------	-----------	---------	--------

2.1 Customer Service Test Program


Activate test mode:	Close door		
	Switch off appliance pos. 0		- Appliance was switched off for at least 5s
	Set program selector to pos. 8		- The following operational sequence must be performed within 15s
	Press key + pos. 9		- Set the program selector to pos. 9, while the „temperature“ key is actuated <i>Start/Pause is flashing</i>
	Release key		- Release the „temperature“ key P:09 is displayed
			- Last occurred error code will be displayed for about 5sec, otherwise nothing will be displayed. See Error search
Select test program:	Set program selector		- Select the test program by setting program selector
	Set program selector to pos. 1		Pos. 1 – Automatic test
	Set program selector to pos. 2		Pos. 2 – Fans (dryer)
	Set program selector to pos. 3	1400	Pos. 3 – Motor (reversing and spinning) Max. spin speed is displayed
	Set program selector to pos. 4		Pos. 4 – Valves
	Set program selector to pos. 5		Pos. 5 – Pump
	Set program selector to pos. 6		Pos. 6 – Heater (washer)

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 000068812 ASP english	Revision: B	Page-No.: 6 of 25
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		


BO – Bosch
NE – Neff



SE – Siemens



Function	Actuation	Display	Remark
	Set program selector to pos. 7	P.07	Pos. 7 – Pressure sensor adjustment
	Set program selector to pos. 8	P.08	Pos. 8 – Not implemented
	Set program selector to pos. 9	P.09	Pos. 9 – Flow sensor
	Set program selector to pos. 10	P.10	Pos. 10 – Not implemented
	Set program selector to pos. 11	P.11	Pos. 11 – Not implemented
	Set program selector to pos. 12	P.12	Pos. 12 – Heater dryer (2 stage)
	Set program selector to pos. 13	P.13	Pos. 13 – Buttons and optical indicator elements
	Set program selector to pos. 14	P.14	Pos. 14 – Not implemented
	Set program selector to pos. 15	P.15	Pos. 15 – Not implemented
Start or restart test program:	Press key →		- Press Start/Pause 2 times to restart a program from the beginning Start/Pause is illuminating
Abort test program:	Press key or → /		- Door stays locked if a security relevant instance is detected (to high water level, -spin speed, or -temperature) Door icon and, or Start/Pause is flashing
Leave test mode:	Set program selector to pos. 0		- The test mode is left also after a mains power blackout




Function	Actuation	Display	Remark
----------	-----------	---------	--------


2.2 Stored error-codes / error search

Activate error search	Close door		- Error search mode activation is possible, even if the appliance is in FATAL ERROR state
	Switch off appliance	pos. 0	
	Set program selector to	pos. 4	- Wait until Start/Pause is flashing Start/Pause is flashing
	Press key +	pos. 5	- Set the program selector to pos. 5, while the „temperature“ key is actuated
	Release key		Start/Pause is switched off
Display of 1st error per monitoring period:	Set program selector		- Select the monitoring period by setting program selector First error, or E:00 is shown
	Set program selector to	pos. 1	First error: / No error: Pos. 1 – First error of the last monitoring period
	Set program selector to	pos. 2	Pos. 2 – First error of the 2nd last monitoring period
	Set program selector to	pos. 3	Pos. 3 – First error of the 3rd last monitoring period
	Set program selector to	pos. 4	Pos. 4 – First error of the 4th last monitoring period
	Set program selector to	pos. 5	Pos. 5 – First error of the 5th last monitoring period
	Set program selector to	pos. 6	Pos. 6 – First error of the 6th last monitoring period

BO – Bosch
NE – Neff



SE – Siemens



Function	Actuation	Display	Remark
	Set program selector to pos. 7	E: / E:00	Pos. 7 – First error of the 7th last monitoring period
	Set program selector to pos. 8	E: / E:00	Pos. 8 – First error of the 8th last monitoring period
	Set program selector to pos. 9-15	No display	Pos. 9-15 – Not implemented
Display of errors:	Press key →	0 error: E:00	- Switch through next occurred error(s) for the selected monitoring period Next error(s), or E:00 is shown
	Press key →	1st error: E:	- If at least one error is stored for the selected monitoring period, then the 1st error stored within this monitoring period is displayed
	Press key →	2nd error: E:	Otherwise E:00 is displayed
		and so on	
Leave error display mode:	Set program selector to pos. 0		- The error display mode is left also after a mains power blackout

3 FUNCTIONS OF SERVICE PROGRAMS

Function	Actuation	Display	Remark		
			Time(s)	Value	Inspection / Corrective


3.1 Customer Service Test Program

Pos. 1 Automatic test





	Press key →	P:01			- Start program	Start/Pause is flashing
Door is locked		P:01				Start/Pause is illuminating
Quick test of all components		P:01				- The sequence is shown on the next page






BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		9 of 25

BO – Bosch
NE – Neff



SE – Siemens









Function	Actuation	Display	Remark	Time(s)	Value	Inspection / Corrective	Note
----------	-----------	---------	--------	---------	-------	-------------------------	------

Pos. 2 Fans (dryer)






	Press key →					- Start program	Start/Pause is flashing
Door is locked							Start/Pause is illuminating
Activation of process air fan				5			
Pause				2			
Activation of cooling air fan				5			
Pause				2			
Activation of process and cooling air fan				5			
Door is unlocked							Start/Pause is flashing



Function	Actuation	Display	Remark	Time(s)	Value	Inspection / Corrective	Note
----------	-----------	---------	--------	---------	-------	-------------------------	------

Pos. 3 Motor

	Press key →					- Start program	Start/Pause is flashing
Door is locked							Start/Pause is illuminating
Pump is activated							
Drum is rotated anticlockwise					50rpm		
Pause				2			
Drum is rotated clockwise					50rpm		
Spin speed is increased to max. spin speed							
Spinning at maximum spin speed				appr. 4min	max. rpm		
Pump is switched off							
Door is unlocked					1400		Start/Pause is flashing



Function	Actuation	Display	Remark		
			Time(s)	Value	Inspection / Corrective






Pos. 4 Valves

	Press key →					- Start program	Start/Pause is flashing
Door is locked							Start/Pause is illuminating
Pump is activated until the appliance is completely drained							
Water inlet via V1 - pre wash				7			
Water inlet via V2 - main wash				10			
Water inlet via V4 - flushing				10			
Water inlet via V1 & V2 – pre- & main wash					1/2 drum-ø		- Water inlet until water level has reached half of drum volume
							- Door remains locked Start/Pause is flashing

Pos. 5 Pump

	Press key →					- Start program	Start/Pause is flashing
Door is locked							Start/Pause is illuminating
Pump is activated until the appliance is completely drained							
Door is unlocked							Start/Pause is flashing

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		13 of 25



Function	Actuation	Display	Remark			Note
			Time(s)	Value	Inspection / Corrective	





Pos. 6 Heater

	Press key →					- Start program	Start/Pause is flashing
Door is locked							Start/Pause is illuminating
Water inlet until heater-on level is reached							
Heater is activated					85°C		
							- Door remains locked Start/Pause is flashing

Pos. 7 Pressure sensor adjustment

	Press key →					- Start program	Start/Pause is flashing
Door is locked							Start/Pause is illuminating
Pump is activated until the appliance is completely drained							
Pressure sensor adjustment starts							
Pressure sensor adjustment ends							
Water inlet via V1 - pre wash					appr. 2-4cm	(measured from drum body up to the water surface)	- Water inlet until target level for measuring is reached
Door is unlocked							Start/Pause is flashing





BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		14 of 25



Function	Actuation	Display	Remark		
			Time(s)	Value	Inspection / Corrective

Pos. 9 Flow rate sensor

	Press key →					- Start program	Start/Pause is flashing
Door is locked							Start/Pause is illuminating
Flow measurement starts							
Water quantity measurement starts							
Pump is activated until the appliance is completely drained							
Water inlet via V1 - pre wash					5 l		
Water quantity measurement ends							
Flow measurement ends							
							- Door remains locked Start/Pause is flashing or error E:29 is displayed



Function	Actuation	Display	Remark			Note
			Time(s)	Value	Inspection / Corrective	





Pos. 12 Heater dryer

	Press key →					- Start program	Start/Pause is flashing
Door is locked							Start/Pause is illuminating
Process- and cooling fan are activated							
Drying heater - stage 1 (low segment) is activated				5			
Drying heater - stage 2 (high segment) is activated				5			
Drying heater - stage 1 (low segment) is switched off							
Pause				5			
Drying heater - stage 2 (high segment) is switched off							
Process- and cooling fan are switched off							
Door is unlocked							Start/Pause is flashing

Pos. 13 Display

	Press key →					- Start program	Start/Pause is flashing
All display segments are activated		All display segments					Start/Pause is illuminating
	Press key →					- Press Start/Pause to abort the program	Start/Pause is flashing

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		16 of 25



4 VARIANT CODING






Function	Actuation	Display	Remark
----------	-----------	---------	--------

4.1 Variant Coding PU

! The variant code is printed at the rating plate at the back of the appliance and at the door label

Activate PU variant coding mode:	Close door		
	Switch off appliance pos. 0		- Appliance was switched off for at least 5s
	Set program selector to pos. 12		Start/Pause is flashing
	Press key → + pos. 11		- Set the program selector to pos. 9, while the „temperature“ key is actuated
	Release key ←		- Release the „temperature“ key Start/Pause is illuminating
Select variant used by PU:	Set program selector		- Select the variant by setting program selector
	Set program selector to pos. 1		Pos. 1 – Machine device class Actual variant code value is displayed
	Set program selector to pos. 2		Pos. 2 – Speed variant Actual variant code value is displayed
	Set program selector to pos. 3		Pos. 3 – Aqua stop / Warm water Actual variant code value is displayed
	Set program selector to pos. 4		Pos. 4 – Water valve variant Actual variant code value is displayed
	Set program selector to pos. 5		Pos. 5 – Door lock variant Actual variant code value is displayed
	Set program selector to pos. 6		Pos. 6 – Flow sensor Actual variant code value is displayed
	Set program selector to pos. 7		Pos. 7 – Turbidity sensor (not used yet) Actual variant code value is displayed





BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		17 of 25



Function	Actuation	Display	Remark
	Set program selector to pos. 8	PU:	Pos. 8 – 3D sensor (not used yet) Actual variant code value is displayed
	Set program selector to pos. 9	PU:	Pos. 9 – Foam wash sensor (not used yet) Actual variant code value is displayed
	Set program selector to pos. 10	PU:	Pos. 10 – Dosage system (not used yet) Actual variant code value is displayed
	Set program selector to pos. 11	PU:	Pos. 11 – VT-Set (not used yet) Actual variant code value is displayed
	Set program selector to pos. 12-15		Pos. 12-15 – Not implemented
Leave PU variant coding mode:	Set program selector to pos. 0		

Pos. 1 Setting machine device class range 0...2

Variant 0: F21	Press key →		PU: 0	- Press any key (except Start/Pause) to change variant code value
Variant 1: S21	Press key →		PU: 1	- Press any key (except Start/Pause) to change variant code value
Variant 2: D21	Press key →		PU: 2	- Press any key (except Start/Pause) to change variant code value



Function	Actuation	Display	Remark
----------	-----------	---------	--------


Pos. 2 Setting speed variant
range 0...7

Variant 0: 1480rpm	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 1: 1200rpm	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 2: 1200rpm	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 3: 1200rpm	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 4: 1200rpm	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 5: 1200rpm	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 6: 1200rpm	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 7: 1200rpm	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value

Pos. 3 Setting Aqua stop / Warm water variant
range 0...3

Variant 0: without Aqua stop	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 1: with Aqua stop, cold water	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 2: with Aqua stop, warm water	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 3: with Aqua stop, cold & warm water	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		19 of 25
The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights including rights created by patent grant or registration of a utility model or design are reserved. Copyright reserved.			



Function	Actuation	Display	Remark
----------	-----------	---------	--------

Pos. 4 Setting water valve variant
range 0...3

Variant 0: Double valve cold	Press key → <input type="checkbox"/>	PU: 0	- Press any key (except Start/Pause) to change variant code value
Variant 1: Triple valve (double cold & flush)	Press key → <input type="checkbox"/>	PU: 1	- Press any key (except Start/Pause) to change variant code value
Variant 2: Triple valve (double cold & warm)	Press key → <input type="checkbox"/>	PU: 2	- Press any key (except Start/Pause) to change variant code value
Variant 3: Double valve (cold & warm)	Press key → <input type="checkbox"/>	PU: 3	- Press any key (except Start/Pause) to change variant code value






Pos. 5 Setting door lock variant
range 0...1

Variant 0: Magnetic door lock	Press key → <input type="checkbox"/>	PU: 0	- Press any key (except Start/Pause) to change variant code value
Variant 1: PTC door lock	Press key → <input type="checkbox"/>	PU: 1	- Press any key (except Start/Pause) to change variant code value

Pos. 6 Setting flow sensor variant
range 0...3

Variant 0: Without flow sensor	Press key → <input type="checkbox"/>	PU: 0	- Press any key (except Start/Pause) to change variant code value
Variant 1: With flow sensor, cold water	Press key → <input type="checkbox"/>	PU: 1	- Press any key (except Start/Pause) to change variant code value
Variant 2: With flow sensor, warm water	Press key → <input type="checkbox"/>	PU: 2	- Press any key (except Start/Pause) to change variant code value
Variant 3: With flow sensor, cold & warm water	Press key → <input type="checkbox"/>	PU: 3	- Press any key (except Start/Pause) to change variant code value

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.:
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		20 of 25



Function	Actuation	Display	Remark
----------	-----------	---------	--------

Pos. 7 Setting turbidity sensor variant – not used yet
range 0...1

Variant 0: Without turbidity sensor	Press key → <input type="text"/>	PU: 0	- Press any key (except Start/Pause) to change variant code value
Variant 1: With turbidity sensor	Press key → <input type="text"/>	PU: 1	- Press any key (except Start/Pause) to change variant code value

Pos. 8 Setting 3D sensor variant – not used yet
range 0...1

Variant 0: 3D Marquard	Press key → <input type="text"/>	PU: 0	- Press any key (except Start/Pause) to change variant code value
Variant 1: 3D Seuffer	Press key → <input type="text"/>	PU: 1	- Press any key (except Start/Pause) to change variant code value

Pos. 9 Setting foam wash sensor variant – not used yet
range 0...1


Variant 0: Without foam wash sensor	Press key → <input type="text"/>	PU: 0	- Press any key (except Start/Pause) to change variant code value
Variant 1: With foam wash sensor	Press key → <input type="text"/>	PU: 1	- Press any key (except Start/Pause) to change variant code value

Pos. 10 Setting dosage system – not used yet
range 0...1

Variant 0: Without dosage system	Press key → <input type="text"/>	PU: 0	- Press any key (except Start/Pause) to change variant code value
Variant 1: With dosage system	Press key → <input type="text"/>	PU: 1	- Press any key (except Start/Pause) to change variant code value

Pos. 11 Setting VT set – not used yet
range 0...1

--	--	--	--



Function	Actuation	Display	Remark
----------	-----------	---------	--------

4.2 OU variant coding

! The variant code is printed at the rating plate at the back of the appliance and at the door label

Activate OU variant coding mode:	Close door		
	Switch off appliance pos. 0		- Appliance was switched off for at least 5s
	Set program selector to pos. 11		Start/Pause is flashing
	Press key → + pos. 10		- Set the program selector to pos. 9, while the „temperature“ key is actuated
	Release key ←		- Release the „temperature“ key Start/Pause is illuminating
Select variant used by OU:	Set program selector		- Select the variant by setting program selector
	Set program selector to pos. 1		Pos. 1 – Acoustic feedback Actual variant code value is displayed
	Set program selector to pos. 2		Pos. 2 – Brand Actual variant code value is displayed
	Set program selector to pos. 3		Pos. 3 – Child proof Actual variant code value is displayed
	Set program selector to pos. 4		Pos. 4 – Load display Actual variant code value is displayed
	Set program selector to pos. 5		Pos. 5 – Panel colour (not used yet) Actual variant code value is displayed
	Set program selector to pos. 6		Pos. 6 – Sales area Actual variant code value is displayed
	Set program selector to pos. 7		Pos. 7 – Overdosage Actual variant code value is displayed
	Set program selector to pos. 8		Pos. 8 – Key variant Actual variant code value is displayed

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.: 22 of 25
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		

BO – Bosch NE – Neff 			SE – Siemens 		
---------------------------------	--	--	----------------------	--	--

Function	Actuation	Display		Remark
	Set program selector to pos. 9			Pos. 9 – Menu variant Actual variant code value is displayed
	Set program selector to pos. 10-15			Pos. 10-15 – Not implemented
Leave OU variant coding mode:	Set program selector to pos. 0			

Pos. 1 Setting acoustic feedback - not used yet
range 0...1

Variant 0: Buzzer	Press key →				- Press any key (except Start/Pause) to change variant code value
Variant 1: Speaker	Press key →				- Press any key (except Start/Pause) to change variant code value

Pos. 2 Setting brand
range 0...1

Variant 0: Siemens	Press key →				- Press any key (except Start/Pause) to change variant code value
Variant 1: Bosch, Neff	Press key →				- Press any key (except Start/Pause) to change variant code value







Pos. 3 Setting child proof
range 0...1

Variant 0: With child proof	Press key →				- Press any key (except Start/Pause) to change variant code value
Variant 1: Without child proof	Press key →				- Press any key (except Start/Pause) to change variant code value

Pos. 4 Setting load display
range 0...1

















Variant 0: With load display	Press key →				- Press any key (except Start/Pause) to change variant code value
Variant 1: Without load display	Press key →				- Press any key (except Start/Pause) to change variant code value

BSH BOSCH UND SIEMENS HAUSGERAETE GMBH	Document-No.: 5500 0000068812 ASP english	Revision: B	Page-No.: 23 of 25
Test Program/Coding Instruction D21-E SWU2	Material-No.: 9000682398		









BO – Bosch NE – Neff 			SE – Siemens 		
---	---	--	---	---	---

Function	Actuation	Display	Remark
----------	-----------	---------	--------









Pos. 5 Setting panel colour – not used yet
range 0...3

Variant 0: White	Press key → 				- Press any key (except Start/Pause) to change variant code value
Variant 1: Silver	Press key → 				- Press any key (except Start/Pause) to change variant code value
Variant 2: Golden/Silver	Press key → 				- Press any key (except Start/Pause) to change variant code value
Variant 3: Stainless steel	Press key → 				- Press any key (except Start/Pause) to change variant code value









Pos. 6 Setting sales area
range 0...1







Variant 0: China	Press key → 				- Press any key (except Start/Pause) to change variant code value
Variant 1: Export	Press key → 				- Press any key (except Start/Pause) to change variant code value

Pos. 7 Setting overdosage
range 0...1

Variant 0: Without overdosage display	Press key → 				- Press any key (except Start/Pause) to change variant code value
Variant 1: With overdosage display	Press key → 				- Press any key (except Start/Pause) to change variant code value







Pos. 8 Setting key variant
range 0...7

Variant 0: Key variant	Press key → 				- Press any key (except Start/Pause) to change variant code value
Variant 1-7: Not used	Press key → 				- Press any key (except Start/Pause) to change variant code value

BO – Bosch NE – Neff 			SE – Siemens 		
---	---	--	---	---	---

Function	Actuation	Display	Remark
----------	-----------	---------	--------

Pos. 9 Setting menu variant
range 0...7

Variant 0: Menu variant	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value
Variant 1-7: Not used	Press key → <input type="text"/>				- Press any key (except Start/Pause) to change variant code value