

WIRING DIAGRAM

S	987																							989	S						
C	1055	1045	1053			1054	1046	1047	1044	1041	1052	1051	1043	1042	1122	1121	1111	1114	1117	1124	1116		1123	1125	1115	C					
C	1057	1127				1002	1072	1000					1407										410			C					
R				1222	1229	1230	1232	1236	1238		1227	1216	1228	1226		1337	1346	1348	1336	1347		1339	1341	1356	1358	1352	1369	1362	R		
R		1245	1241	1239	1242	1244	1219	1221	1215	1211	1210	1212	1218	1209	1217	1207	1208	1338	1229	1332	1330	1331	1335	1363	1364	1359	1361	1350	1362	1365	R
R		1247	1367	1246	1366	1439		1161	1261													410								R	

