

WIRING DIAGRAM

S	987																			989	S
C	1055 1045 1053	1054	1046 1047	1044	1041 1052 1051 1043	1042 1122 1121 1111	1114	1117	1124 1116	1123 1125 1115					C						
C	1057 1127											1407					C				
R	1222 1229 1230 1232 1236+1238												1227 1216 1228 1226	1337 1346 1348 1336 1347	1339-1341 1356-1358 1352 1349 1342			R			
R	1245	1241	1239	1242-1244	1219-1221	1215 1211	1210 1212 1218	1209 1217 1207 1208	1338 1229 1332 1330	1331 1335 1363	1364 1359 1361 1350 1362 1365			R							
R	1247 1367 1246 1366 1439												1141 1261						R		

