


**HiFi ENGINE®**

For more Hi-Fi manuals and set-up information  
please visit [www.hifiengine.com](http://www.hifiengine.com)

⚠ Means important safety item, which must be replaced, when necessary, by a part specified or meeting the specification by the manufacturer.



Europe	R301	L301	C304	C305	C309	C311	C705	C7	C8	C131
Australia & U.K.	R302	L302	C306	C306	C310	C312	0.1/250VAC	0.0047	0.01	220p
U.S.A. Canada	JUMPER	Not Used	Not Used	100p	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used
U.S.A. Canada	U.S.A. Canada	U.S.A. Canada	U.S.A. Canada	U.S.A. Canada	U.S.A. Canada	U.S.A. Canada	U.S.A. Canada	U.S.A. Canada	U.S.A. Canada	U.S.A. Canada

Area	EQ & POWER UNIT	P. SUPPLY & UNIT	POWER TRANS P. No.
Europe	1U-1808B	1U-1623	233564003
U.S.A. and Canada	1U-1808D	1U-1624A	233565901
Asia	1U-1808D	1U-1624B	233566102
Australia	1U-1808B	1U-1623K	233565703
U.K.	1U-1808B	1U-1623K	233565703

NOTES  
 ALL RESISTANCE VALUES IN OHM k = 1,000 OHM M = 1,000,000 OHM  
 ALL CAPACITANCE VALUES IN MICRO FARAD P = MICRO-MICRO FARAD  
 EACH VOLTAGE AND CURRENT ARE MEASURED AT NO SIGNAL INPUT CONDITION  
 CIRCUIT AND PARTS ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.