


CR - ELECTRONIC OVEN CONTROL UNIT
E1 - UPPER HEATING ELEMENT
F1 - ROUND HEATING ELEMENT
H1 - LOWER HEATING ELEMENT
L1 - OVEN LAMP
K2 - LED SIGNAL LAMP
M1 - CAVITY FAN
M2 - DUAL SPEED COOLING FAN
M3 - TURNSPIT
MB - DOOR LATCH MOTOR
S1 - ELECTRONIC SENSOR
SW/B - DOOR LATCH SWITCH
SW/P - DOOR SWITCH
SW/EL - POWER SUPPLY ELEM. SWITCH
SW/F1 - AUXILIARY SWITCH
Y1 - THERMOLIMITER
Y3 - THERMOLIMITER
W - MAIN TERMINAL BLOCK
X9 - UPPER HEATING EARTHING
Y4 - THERMOLIMITER

00 - BLACK
11 - BROWN
22 - RED
33 - ORANGE
44 - YELLOW
55 - GREEN
66 - BLUE
77 - VIOLET
99 - WHITE
09 - WHITE-BLACK
29 - WHITE-RED
49 - WHITE-YELLOW
69 - WHITE-BLUE
90 - GREY
92 - PINK
45 - YELLOW-GREEN

CONNECTORS LEGEND
P001 - ELECTRONIC MODULE SUPPLY
X3-EARTH - N-NEUTRAL - L2-LINE
P002 - LOW POWER DEVICES
P004 - DOOR LATCH
1-DOOR LATCH - 2-DOOR SWITCH - 3-STROBE
P005 - OVEN SENSOR
P008 - G2/EVO DISPLAY CONNECTION

N2 - POWER SUPPLY

RELAYS LEGEND
RL2 - DOOR LATCH MOTOR
RL4 - BOTTOM HEATING ELEMENT - H1
RL1 - ROUND HEATING ELEMENT - F1
RL3 - UPPER/GRILL HEATING ELEMENT - E1

RL6 -
RL9 - CAVITY FAN - M1
RL8 - COOLING FAN - M2
RL7 - CAVITY LIGHT - L1

W11518853