

**TOSHIBA**  
Leading Innovation >>>

REVISED:01

## SERVICE MANUAL

LCD Color Television

**50L2353D(N)**

## **REVISION HISTORY**

REV	Date	Reason for Change
1	Dec/19/2014	Addition of "AFTER MAIN PCB REPLACEMENT".

# **CONTENTS**

1. IMPORTANT NOTICE
2. GREEN PRODUCT PROCUREMENT
3. LEAD-FREE SOLDER
4. SAFETY INSTRUCTION
5. HOTEL MODE
6. COPYING HOTEL MODE SETTING
7. FIRMWARE UPDATING
8. INTERCONNECT
9. EXPLODED VIEW
10. PANEL IDENTIFICATION
- △ 11. AFTER MAIN PCB REPLACEMENT
12. DESTINATION SETTING CHANGE

# **IMPORTANT NOTICE**

## **WARNING:**

You are requested that you shall not modify or alter the information or data provided herein without prior written consent by Toshiba. Toshiba shall not be liable to anybody for any damages, losses, expenses or costs, if any, incurred in connection with or as a result of such modification or alteration.

**THE INFORMATION OR DATA HEREIN SHALL BE PROVIDED "AS IS" WITHOUT ANY WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

Toshiba shall not be liable for any damages, losses, expenses or costs, if any, incurred in connection with or as a result of use of any information or data provided herein.

# GREEN PRODUCT PROCUREMENT

The EC is actively promoting the WEEE & RoHS Directives that define standards for recycling and reuse of Waste Electrical and Electronic Equipment and for the Restriction of the use of certain Hazardous Substances. From July 1, 2006, the RoHS Directive will prohibit any marketing of new products containing the restricted substances.

Increasing attention is given to issues related to the global environmental. Toshiba Corporation recognizes environmental protection as a key management tasks, and is doing its utmost to enhance and improve the quality and scope of its environmental activities. In line with this, Toshiba proactively promotes Green Procurement, and seeks to purchase and use products, parts and materials that have low environmental impacts.

Green procurement of parts is not only confined to manufacture. The same green parts used in manufacture must also be used as replacement parts.

## LEAD-FREE SOLDER

This product is manufactured using lead-free solder as a part of a movement within the consumer products industry at large to be environmentally responsible. Lead-free solder must be used in the servicing and repair of this product.

**WARNING: This product is manufactured using lead free solder.  
DO NOT USE LEAD BASED SOLDER TO REPAIR THIS PRODUCT!**

The melting temperature of lead-free solder is higher than that of leaded solder by 30°C to 40°C (54°F to 72°F). Use of a soldering iron designed for lead-based solders to repair product made with lead-free solder may result in damage to the component and or PCB being soldered. Great care should be made to ensure high-quality soldering when servicing this product especially when soldering large components, through-hole pins, and on PCBs as the level of heat required to melt lead-free solder is high.

# SAFETY INSTRUCTION

**WARNING: BEFORE SERVICING THIS CHASSIS, READ THE "SAFETY PRECAUTION" AND "PRODUCT SAFETY NOTICE" INSTRUCTIONS BELOW.**

## Safety Precaution


**WARNING: SERVICING SHOULD NOT BE ATTEMPTED BY ANYONE UNFAMILIAR WITH THE NECESSARY PRECAUTIONS ON THIS RECEIVER. THE FOLLOWING ARE THE NECESSARY PRECAUTIONS TO BE OBSERVED BEFORE SERVICING THIS CHASSIS.**

1. An isolation transformer should be connected in the power line between the receiver and the AC line before any service is performed on the receiver.
2. Always disconnect the power plug before any disassembling of the product. It may result in electrical shock.
3. When replacing a chassis in the cabinet, always be certain that all the protective devices are put back in place, such as nonmetallic control knobs, insulating covers, shields, isolation resistor-capacitor network, etc.
4. Always keep tools, components of the product, etc away from the children, These items may cause injury to children.
5. Depending on the model, use an isolation transformer or wear suitable gloves when servicing with the power on, and disconnect the power plug to avoid electrical shock when replacing parts. In some cases, alternating current is also impressed in the chassis, so electrical shock is possible if the chassis is contacted with the power on.
6. Always use the replacement parts specified for the particular model when making repairs. The parts used in products require special safety characteristics such as inflammability, voltage resistance, etc. therefore, use only replacement parts that have these same characteristics. Use only the specified parts when the  mark is indicated in the circuit diagram or parts list.
7. Parts mounting and routing dressing of wirings should be the same as that used originally. For safety purposes, insulating materials such as isolation tube or tape are sometimes used and printed circuit boards are sometimes mounted floating. Also make sure that wirings is routed and clamped to avoid parts that generate heat and which use high voltage. Always follow the manufactured wiring routes / dressings.

8. Always ensure that all internal wirings are in accordance before re-assembling the external casing after a repairing completed. Do not allow internal wiring to be pinched by cabinets, panels, etc. Any error in reassembly or wiring can result in electrical leakage, flame, etc., and may be hazardous.
  
9. NEVER remodel the product in any way. Remodeling can result in improper operation, malfunction, or electrical leakage and flame, which may be hazardous.
  
10. Touch current check. (After completing the work, measure touch current to prevent an electric shock.)
  - Plug the AC cord directly into the AC outlet. Do NOT use an isolation transformer for this check.
  - Connect a measuring network for touch currents between each exposed metallic part on the set and a good earth ground such as a water pipe.

Annex D  
(normative)

Measuring network for TOUCH CURRENTS



Resistance values in ohms ( $\Omega$ ).

V: Voltmeter or oscilloscope  
(r.m.s. or peak reading)

Input resistance :  $\geq 1 \text{ M}\Omega$

Input capacitance :  $\leq 200 \text{ pF}$

Frequency range : 15 Hz to 1 MHz and d.c. respectively

**Note:** Appropriate measures should be taken to obtain the correct value in case of non sinusoidal waveforms.

The measuring instrument is calibrated by comparing the frequency factor of  $U_2$  with the solid line in figure F.2 of IEC 60990 at various frequencies. A calibration curve is constructed showing the deviation of  $U_2$  from the ideal curve as a function of frequency.

TOUCH CURRENT =  $U_2 / 500$  (peak value).

- The potential at any point (TOUCH CURRENT) expressed as voltage  $U_1$  and  $U_2$  does not exceed the following value:

The part or contact of a TERMINAL is not HAZARDOUS LIVE if:

- a) The open-circuit voltage should not exceed 35 V (peak) a.c. or 60 V d.c. or, if a) is not met.
- b) The measurement of the TOUCH CURRENT shall be carried out in accordance with IEC 60990, with the measuring network described in **Annex D** of this standard.

The TOUCH CURRENT expressed as voltages  $U_1$  and  $U_2$ , does not exceed the following values:

- for a.c. :  $U_1 = 35$  V (peak) and  $U_2 = 0.35$  V (peak);
- for d.c. :  $U_1 = 1.0$  V

**Note:** The limit values of  $U_2 = 0.35$  V (peak) for a.c. and  $U_1 = 1.0$  V for d.c. correspond to the values 0.7 mA (peak) a.c. and 2.0 mA d.c.

## Product Safety Notice

Many electrical and mechanical parts in this chassis have special safety-related characteristics. These characteristics are often passed unnoticed by a visual inspection and the protection afforded by them cannot necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this manual and its supplements; electrical components having such features are identified by the international hazard symbols on the schematic diagram and the parts list.

Before replacing any of these components, read the parts list in this manual carefully. The use of substitute replacement parts which do not have the same safety characteristics as specified in the parts list may create electrical shock, fire, or other hazards.

# HOTEL MODE

		Function	Setting *off(normal set)		Information
1	1	Hotel Mode On/Off	Off/On	Off	Hotel mode enable *On: hotel mode on
	2	Panel Lock	Off/On	Off	Inhibit all buttons which are on TV body *On: not available Side key
	3	Panel Lock W/O Input Selector Keys.	Off/On	Off	Inhibit all buttons which are on TV body only disable input key *On: not available Side key only disable input key
	4	Disable Remote Control	Off/On	Off	Inhibit the remote control. *Setting is enable at the Service mode. *On: not available remote control
	5	Disable All Menu	Off/On	Off	*On: All of user menu will be disabled. *Off: All of user menu will work normally.
	6	Disable Setup Menu	Off/On	Off	Inhibit set up menu *On: set up menu Inhibit
	7	Setup Menu W/O Lang.	Off/On	Off	Inhibit display set up menu except for language setting. *There is only language setting at the Setup menu. *On: only lang. display at setup menu.

	8	Max Volume Setting	0~100[dec]	100	Max volume control Max vol setting Method: Setting 100 volume, and turning and choice this value.
	9	Digital Tuner	Off/On	On	DTV source selection depends on Digital Tuner setting. *On: enable DTV *Off: hide DTV
	10	USB Port	Off/On	On	MEDIA source selection depends on USB port setting. *On: enable MEDIA in inputs menu *Off: hide MEDIA in inputs menu *Off (Enable 5V): Disable USB, but enable the 5V power.
	11	TV to USB	NO/YES	NO	It will clone the data of TV to USB disk. The data includes user setting, the setting of hotel mode and channel table.
	12	USB to TV	NO/YES	NO	It will clone the data of USB disk to TV. The data includes user setting, the setting of hotel mode and channel table.
	13	Disable NIT Update	Off/On	Off	*On: enable NIT update *Off: disable NIT update
	14	Detect SCART	On / Off	On	ON: Pin8 will go on normal operation and it is going to switch between sources automatically. Off: Pin8 is ignored and the automatic source switching would be enabled.

		Off/ On(AC)/ On	Off	Remote control power button on or TV power switch (on side body) on, then display goes to fixed POS/Video (= nealy equal #9)  *On: fixed pos/video set  *On (AC): TV tunes to preset “Pos/Video” (channel or input) only when AC power is applied. When TV is powered on by power button, tune to the last channel or input.	
	1	Fixed Pos/Video	ATV(0~99)/SCART/AV/ YPBPR/HDMI1/HDMI2/ PC/DTV	*TV, Component, AV,..., PC,HDMI,...,Off TV:1~255[dec] (normal:0) DTV: depends on channel auto tuning	
2	2	Fixed Volume	Off/On 0~100[dec] (normal:50)	Remote control power button on or TV power switch(on side body) on , then forced volume setting  *101~ : not available	
	3	Fixed Picture Mode	Off/On 0:Dynamic(Default) 1:Standard 2:Mild 3:Movie 4:Memory	Remote control power button on or TV power switch(on side body) on, then picture mode is selected  *On: Fixed selectable Pic.	
	4	Welcome Message	Off/On	Off	Remote control power button on or TV power

		1:Default 2:8 Sec. 3:15 Sec.		switch(on side body) on, then fixed "Welcome to our hotel" Message is displayed. 'Until first operation' means that first event for TV occur (ex. Ch up).
5	Update Welcome Message	YES/NO	NO	<p>It will update the logo, when TV on the new logo show.</p> <p>*Using USB, user replaces the user original message with the default welcome message.</p> <p>As below is message, the file limitation items:</p> <ol style="list-style-type: none"> <li>1. File format should be JPG file.</li> <li>2. JPG Resolution &lt;= 1360 x 768.</li> <li>3. JPG file size &lt; 64KB.</li> <li>4. JPG file name is "Hotel_Logo.jpg".</li> </ol>
6	Teletext	Off/On	On	<p>Teletext functions are depend on Teletext setting</p> <p>*On: enable Teletext functions and operation</p> <p>*Off: disable Teletext functions and operation</p>
7	ATV/DTV P+/P-	Off/On	Off	<p>*On: enable ATV/DTV P+/P-</p> <p>*Off: disable ATV/DTV P+/P</p>
8	TV Power	Disabled/ On/ Standby	Disabled	<p>*Disabled: TV returns to previous Standby/On state when AC power is applied.</p> <p>*On: Power TV on when AC power is applied.</p> <p>*Standby: Put TV in Standby when AC power is applied.</p>
9	Reset Menu	YES/NO	NO	Set to default all setting in Hotel mode menu

How to enter Hotel Mode.

- 1) Press “MUTE” button on the remote, and display [mute].
- 2) Within 2 sec, press “MUTE” button on the remote again, and hold the button down for 3 sec.
- 3) Then, press “INPUT” button on the TV side. Then hotel mode menu will appear.

How to exit Hotel mode.

Turn the TV power off

# Copying Hotel Mode Setting

**TV to USB:**  
Copying a BIN file into USB flash.

Hotel Menu		
1	2	
Hotel Mode On/Off		On
Panel Lock		Off
Panel Lock W/O Input Selector Keys.		Off
Disable Remote Control		Off
Disable All Menu		Off
Disable Setup Menu		Off
Setup Menu W/O Lang.		Off
Max Volume Setting		100
Digital Tuner		On
USB Port		On
<b>TV to USB</b>	◀	YES ▶
USB to TV		NO
Disable NIT Update		Off
Detect SCART		On

**USB to TV:**  
Copying a BIN file into TV.

Hotel Menu		
1	2	
Hotel Mode On/Off		On
Panel Lock		Off
Panel Lock W/O Input Selector Keys.		Off
Disable Remote Control		Off
Disable All Menu		Off
Disable Setup Menu		Off
Setup Menu W/O Lang.		Off
Max Volume Setting		100
Digital Tuner		On
USB Port		On
TV to USB		NO
<b>USB to TV</b>	◀	YES ▶
Disable NIT Update		Off
Detect SCART		On

# Copying Hotel Mode Setting

## TV to USB Step :

1. Insert USB flash disk into TV USB port.
2. Please press “MUTE” key twice (MUTE icon disappear) , at the same time, press “SOURCE” by keypad for a while.  
->“Hotel Menu” will come out.
3. Select the item “TV to USB” and press Left or Right button to choose “YES”. Then press “OK” button.  
->The hotel settings will copy into USB disk with file name **HOTEL\_xxx23xxx.BIN**
4. Once copy is finished. The OSD message “**Please wait...**” will disappear then shown “**OK!** ” message.

# Copying Hotel Mode Setting

## USB to TV Step (method 1) :

1. Insert USB disk with available file into TV USB port.
  
2. Please press “MUTE” key twice (MUTE icon disappear) , at the same time, press “SOURCE” by keypad for a while.  
->“Hotel Menu” will come out.
  
3. Selecting the item “USB to TV ” and press Left or Right button to choose “YES”. Then press “OK” button.  
->The hotel settings will copy from USB to TV with file name **HOTEL\_xxx23xxx.BIN**.
  
4. Once copy is finished. The OSD message “**Please wait...**” will disappear then shown "**Please remove USB memory, then TV will be reset automatically**" message.



# Copying Hotel Mode Setting

## USB to TV Step (method 2) :

1. Insert USB disk with available file into TV USB port.
  
2. Please reboot (AC Off/On) TV to update hotel settings automatically.  
->the set will shown “Hotel Mode Settings Update Please Wait”.
  
3. The OSD message “Please wait...” will disappear then shown “Update is finished .Please remove USB memory, then TV will be reset automatically.”
  
4. Please remove USB disk then turn AC Off/On to reboot TV. The new settings will be active.

# Firmware Upgrade – USB

1. Copying a firmware BIN file to USB disk. (root directory)
2. Plug in USB disk to TV USB port.
3. Reboot (AC Off/On) TV to update F/W automatically.
4. During firmware upgrade will have display a OSD on LCD screen and power status LED will be blinking.
5. When F/W upgrade is finished, a message on screen will be shown then unplug USB disk.
6. TV will be reset automatically.



## Definition of Firmware file name


File name: **xxx23xxx\_001\_REV00.bin.**

**xx:** for all TV size.

**x23xxx:** model series.


001 : firmware version ex 001 is 0.01, 100 is 1.00

REV00: fixed for revision 00



## Exploded View

50L2353D



**Note:**  
Please see PPL put on Web-PRESS for the latest information or other parts.

SAFETY PRECAUTION


The parts identified by  mark are critical for safety. Replace only with part number specified. The mounting position of replacement is to be identical with originals. The substitute replacement parts which do not have the same safety characteristics as specified in the parts list may create shock, fire or other hazards.

50L2353D(N)

No.	Location	Toshiba Service Part	ODM Partner Part	Description
1+2+3	E100	75033887	13EB-43B0601	FRONT COVER (FRONT BEZEL)
5	E106	75034305	13EB-43Q0W11	SUPPORT FOR SMALL BOARD
6	⚠ E300	75032896		LCD PANEL, LG, LC500DUE-SFR1
9	⚠ E250	75033897	0433-008C000	POWER BOARD ASSY
10	E200	75036403	9C-EB40M0370	MAIN BOARD ASSY
11	E140	75033892	13EB-43B0H01	SIDE KEY BEZEL ASSY
12	E330	75029565	044A-012X000	SPEAKER (LEFT AND RIGHT)
13	E110	75035513	13EB-43Q1211	BACK COVER ASSY
14+15	E150	75033894	13EB-43B0901	NECK ASSY
		75033895	13EB-43B0K01	
16+17+18+(19-2)	E120	75036648	13EB-43B0C11	STAND ASSY
		75036649	13EB-43B0P11	
33	E260	75033758	9C-EB40S0250	LED BOARD ASSY
34	E270	75033759	9C-EB40S0270	IR BOARD ASSY

# PANEL IDENTIFICATION

Serial No. part printed on Rating Label



## Panel Identification Code

Marking	Panel Vendor	Marking	Panel Vendor	Marking	Panel Vendor
A	AUO	J		S	SHARP
B	BriView	K	SAMSUNG	T	
C	CMO	L	LPL/LGD	U	
D	CHILIN	M		V	
E		N		W	
F		P	CPT	X	
G		Q		Y	
H	IPS	R		Z	

# AFTER MAIN PCB REPLACEMENT


The following setting must be checked after PCB replacement to make sure, that PCB setting corresponds to the panel type:

**1. Enter Factory Menu:**

- MENU
- Applications
- Sleep Timer + "2766"

**2. Go to page 3 and select the proper panel type (take care of the full panel name, not only panel vendor name).**

Panel type can be found on the panel serial number sticker.



3. Press EXIT to leave the factory mode (please make sure you have selected the proper panel type, before you press EXIT !).
4. If the proper panel type was set, TV will come up with proper picture after TV restart.

**PLEASE TAKE CARE:** set may come up with NO PICTURE at all when wrong panel was selected and it will be very difficult/impossible to adjust the proper settings afterwards.

## DESTINATION SETTING CHANGE

Whenever replacing the Main PCB with new one, perform this procedure.

1. IR Key MENU → APPLICATIONS → Sleep Timer → OK.
2. When display \_ \_ : \_ 0 input 4 numbers 2766.



The Factory menu will display.




3. Move to Tag "3" by Right/Left Arrow key on the Remote.
4. Select "Model Type" cell.



5. Select the appropriate model type by Right/Left Arrow key on the Remote.



6. Select "Reset to Def".
7. Select "Yes" and press "OK" button on the Remote.



**TOSHIBA LIFESTYLE PRODUCTS & SERVICES CORPORATION**  
**2-9, Suehiro-Cho, Ome-Shi, Tokyo 198-8710, Japan**


REV. 01  
Dec/19/2014

## **CONTENTS**

## **REVISION HISTORY**

Date	Author	Ver	Comments
2012/09/03	Jeff/Webb	1.00	For SR stage.
2012/12/17	Jeff/Webb	1.01	For MP stage.

<b>Uniham</b>		<b>Title :</b>	Contents&History	
		<b>Engineer:</b>	Jeff Y Hsiao/Webb Chen	
<b>LED BOARD</b>				
Size	Project Name			Rev
B	<b>L2300</b>			1.01
Date:	Monday, March 18, 2013	Sheet	1	of 2




# CONTENTS


SCHEMATIC Name	SHEET
01.Contents & History	1
02.TV System Power Budget	2
03.MB Block Diagram	3
04.DC to DC	4
05.MSD8841-3A3D&USB&AUDIO	5
06.MSD8841-DDR&LVDS&GPIO	6
07.MSD8841_POWER	7
08.MSD8841-CI&TFE&TS&NAND	8
09.MEMORY DDR3	9
10.PCMCIA CONN	10
11.HDMI and MHL	11
12.VGA	12
13.COMPONENT and AV	13
14.SCART	14
15.SPEAKER&EARPHONE AMP	15
16.TUNER	16
17.LVDS	17
18.SPdif	18
19.USB	19
20.NAND FLASH	20
21.Ethernet CONN	21
22.MSB1230	22
23.IR_ALS	23


# REVISION HISTORY

Date	Author	Ver	Comments
2012/08/27	Jeff/Jerry	1.00	For SR stage.
2012/09/14	Jeff/Jerry	1.01	For SR2 stage.
2012/10/20	Jeff/Jerry	1.02	For ER stage.
2012/11/07	Jeff/Jerry	1.03	For ER2 stage.
2012/11/21	Jeff/Jerry	1.03a	For PR stage.


# TV System Power Budget Block Diagram









<b>Unihan</b>		Title : DC to DC
MAIN BOARD		Engineer: Jeff Y Hsiao/Jerry Lo
Size B	Project Name <b>L2300</b>	Rev 1.03a
Date: Thursday, December 20, 2012		
Sheet 4 of 23		








**Unihan** Title : **MSD8841**


MAIN BOARD Engineer: **Jeff Y Hsiao/Jerry Lo**

Size Project Name Rev  
Custom **L2300** 1.03a

Date: Thursday, December 20, 2012 Sheet 7 of 23




Unihan		Title : MSD8841	
MAIN BOARD		Engineer: Jeff Y Hsiao/Jerry Lo	
Size	Project Name	Rev	
B	L2300	1.03a	
Date: Thursday, December 20, 2012	Sheet 1	8	of 23




Component list for the left side:

- 6 A-TMA12 RN7D 8 7 22 OHM A-MA12
- 6 A-TMBA1 RN7C 6 5 22 OHM A-MBA1
- 6 A-TMA10 RN7B 4 3 22 OHM A-MA10
- 6 A-TMCKE RN7A 2 1 22 OHM A-MCKE
- 6 A-TMA1 RN8D 8 7 22 OHM A-MA1
- 6 A-TMRA8B RN8C 6 5 22 OHM A-MRASB
- 6 A-TMA11 RN9B 4 3 22 OHM A-MA11
- 6 A-TMA14 RN9A 2 1 22 OHM A-MA14
- 6 A-TMA2 R185 2 1 22 OHM A-MA2
- 6 A-TMA0 R186 2 1 22 OHM A-MA0
- 6 A-TMA2A RN10D 8 7 22 OHM A-MA2A
- 6 A-TMBA0 RN10C 6 5 22 OHM A-MBA0
- 6 A-TMA3 RN10B 4 3 22 OHM A-MA3
- 6 A-TMA5 RN10A 2 1 22 OHM A-MA5
- 6 A-TMA9 RN11D 8 7 22 OHM A-MA9
- 6 A-TMA13 RN11C 6 5 22 OHM A-MA13
- 6 A-TMA17 RN11B 4 3 22 OHM A-MA7
- 6 A-TMRESETB RN11A 2 1 22 OHM A-MRESETB
- 6 A-TMODT R187 2 1 22 OHM A-MODT
- 6 A-TMWEB R188 2 1 22 OHM A-MWEB
- 6 A-TMKB R189 2 1 22 OHM A-MCKB
- 6 A-TMCK R190 2 1 22 OHM A-MCK
- 6 A-TMDMU RN12D 8 7 22 OHM A-MDMU
- 6 A-TMDQL2 RN12C 6 5 22 OHM A-MDQL2
- 6 A-TMDQL6 RN12B 4 3 22 OHM A-MDQL6
- 6 A-TMDQL4 RN12A 2 1 22 OHM A-MDQL4
- 6 A-TMDQU7 RN13D 8 7 22 OHM A-MDQU7
- 6 A-TMDQU1 RN13C 6 5 22 OHM A-MDQU1
- 6 A-TMDQU5 RN13B 4 3 22 OHM A-MDQU5
- 6 A-TMDQU3 RN13A 2 1 22 OHM A-MDQU3
- 6 A-TMDQL0 R191 2 1 22 OHM A-MDQL0
- 6 A-TMDQL3 RN14D 8 7 22 OHM A-MDQL3
- 6 A-TMDML RN14C 6 5 22 OHM A-MDML
- 6 A-TMDQL7 RN14B 4 3 22 OHM A-MDQL7
- 6 A-TMDQL5 RN14A 2 1 22 OHM A-MDQL5
- 6 A-TMDQSLB R192 2 1 22 OHM A-MDQSLB
- 6 A-TMDQSL R193 2 1 22 OHM A-MDQSL
- 6 A-TMDQSUB R194 2 1 22 OHM A-MDQSUB
- 6 A-TMDQSU R195 2 1 22 OHM A-MDQSU
- 6 A-TMDQO2 R196 2 1 22 OHM A-MDQO2
- 6 A-TMDQO6 RN15D 8 7 22 OHM A-MDQO6
- 6 A-TMDQO4 RN15C 6 5 22 OHM A-MDQO4
- 6 A-TMDQO0 RN15B 4 3 22 OHM A-MDQO0
- 6 A-TMDQL1 RN15A 2 1 22 OHM A-MDQL1




Component list for the middle section:

- A-MVREFCA M8 VREFCA DQ0 E3 A-MDQL0
- A-MVREFDQ H1 VREFDQ DQ1 F7 A-MDQL1
- A-MA0 N3 DQ2 A-MDQL2
- A-MA1 P7 A0 DQ3 A-MDQL3
- A-MA2 P3 A1 DQ4 A-MDQL4
- A-MA3 N2 A2 DQ5 A-MDQL5
- A-MA4 P8 A3 DQ6 A-MDQL6
- A-MA5 P2 A4 DQ7 A-MDQL7
- A-MA6 R8 A5 DQ8 A-MDQ0
- A-MA7 R2 A6 DQ9 A-MDQ1
- A-MA8 T8 A7 DQ10 A-MDQ2
- A-MA9 R3 A8 DQ11 A-MDQ3
- A-MA10 L7 A9 DQ12 A-MDQ4
- A-MA11 R7 A10 DQ13 A-MDQ5
- A-MA12 N7 A11 DQ14 A-MDQ6
- A-MA13 T3 A12 DQ15 A-MDQ7
- B-TMA12 NC RN16B 4 3 B-MA12
- B-TMA1 RN16A 2 1 B-MBA1
- B-TMA10 NC RN18A 2 1 B-MA10
- B-TMWEB NC RN18D 8 7 B-MWEB
- B-TMA1 RN17B 4 3 B-MA1
- B-TMA8 RN17A 2 1 B-MA8
- B-TMA6 RN16D 8 7 B-MA6
- B-TMA4 RN16C 6 5 B-MA4
- B-TMCA8 NC RN18C 6 5 B-MCASB
- B-TMRASB NC RN18B 4 3 B-MRASB
- B-TMA11 NC RN17D 8 7 B-MA11
- B-TMA14 NC RN17C 6 5 B-MA14
- B-TMBA2 NC R197 2 1 B-MBA2
- B-TMA0 NC R198 2 1 B-MA0
- B-TMA2 NC RN19A 2 1 B-MA2
- B-TMBA0 NC RN19D 8 7 B-MBA0
- B-TMA3 NC RN19C 6 5 B-MA3
- B-TMA5 NC RN19B 4 3 B-MA5
- B-TMA9 NC RN20C 6 5 B-MA9
- B-TMA13 NC RN20B 4 3 B-MA13
- B-TMA7 NC RN20D 8 7 B-MA7
- B-TMRESETB NC RN20A 2 1 B-MRESETB
- B-TMODT NC R201 2 1 B-MODT
- B-TMCKE NC R202 2 1 B-MCKE
- B-TMCK NC R203 2 1 B-MCK
- B-TMCKB NC R204 2 1 B-MCKB
- B-TMDQLO NC RN21D 8 7 B-MDQL0
- B-TMDQ1 NC RN21C 6 5 B-MDQL1
- B-TMDQ6 NC RN21B 4 3 B-MDQL6
- B-TMDQ4 NC RN21A 2 1 B-MDQL4
- B-TMDQ07 NC RN22B 4 3 B-MDQ07
- B-TMDQ11 NC RN22A 4 3 B-MDQ11
- B-TMDQ3 NC RN22C 6 5 B-MDQ3
- B-TMDQ5 NC RN22D 8 7 B-MDQ5
- B-TMDQ5 NC R205 2 1 B-MDQL5
- B-TMDQ3 NC RN23C 6 5 B-MDQL3
- B-TMDQ6 NC RN23D 8 7 B-MDQL6
- B-TMDQ7 NC RN23A 2 1 B-MDQL7
- B-TMDQ2 NC RN23B 4 3 B-MDQL1
- B-TMDQ02 NC RN24A 2 1 B-MDQ02
- B-TMDQSL NC R206 2 1 B-MDQSL
- B-TMDQSL NC R207 2 1 B-MDQSL
- B-TMDQSUB NC R208 2 1 B-MDQSUB
- B-TMDQSU NC R209 2 1 B-MDQSU
- B-TMDMU NC R210 2 1 B-MDMU
- B-TMDQ06 NC RN24B 4 3 B-MDQ06
- B-TMDQ04 NC RN24D 8 7 B-MDQ04
- B-TMDQ00 NC RN24C 6 5 B-MDQ00
- B-TMDQ1 NC RN23B 4 3 B-MDQL1





Component list for the right side:


- B-MVREFCA M8 VREFCA DQ0 E3 B-MDQL0
- B-MVREFDQ H1 VREFDQ DQ1 F7 B-MDQL1
- B-MA0 N3 DQ2 B-MDQL2
- B-MA1 P7 A0 DQ3 B-MDQL3
- B-MA2 P3 A1 DQ4 B-MDQL4
- B-MA3 N2 A2 DQ5 B-MDQL5
- B-MA4 A3 DQ6 B-MDQL6
- B-MA5 P2 A4 DQ7 B-MDQL7
- B-MA6 R8 A5 DQ8 B-MDQ0
- B-MA7 R2 A6 DQ9 B-MDQ1
- B-MA8 T8 A7 DQ10 B-MDQ2
- B-MA9 R3 A8 DQ11 B-MDQ3
- B-MA10 L7 A9 DQ12 B-MDQ4
- B-MA11 R7 A10 DQ13 B-MDQ5
- B-MA12 N7 A11 DQ14 B-MDQ6
- B-MA13 T3 A12 DQ15 B-MDQ7
- B-MDQL0 NC RN16B 4 3 B-MA12
- B-MDQL1 NC RN16A 2 1 B-MBA1
- B-MDQL2 NC RN18A 2 1 B-MA10
- B-MDQL3 NC RN18D 8 7 B-MWEB
- B-MDQL4 NC RN17B 4 3 B-MA1
- B-MDQL5 NC RN17A 2 1 B-MA8
- B-MDQL6 NC RN16D 8 7 B-MA6
- B-MDQL7 NC RN16C 6 5 B-MA4
- B-MDQ0 NC RN18C 6 5 B-MCASB
- B-MDQ1 NC RN18B 4 3 B-MRASB
- B-MDQ2 NC RN17D 8 7 B-MA11
- B-MDQ3 NC RN17C 6 5 B-MA14
- B-MDQ4 NC R197 2 1 B-MBA2
- B-MDQ5 NC R198 2 1 B-MA0
- B-MDQ6 NC RN19A 2 1 B-MA2
- B-MDQ7 NC RN19D 8 7 B-MBA0
- B-MDQ8 NC RN19C 6 5 B-MA3
- B-MDQ9 NC RN19B 4 3 B-MA5
- B-MDQ10 NC RN20C 6 5 B-MA9
- B-MDQ11 NC RN20B 4 3 B-MA13
- B-MDQ12 NC RN20D 8 7 B-MA7
- B-MDQ13 NC RN20A 2 1 B-MRESETB
- B-MODT NC R201 2 1 B-MODT
- B-MCKE NC R202 2 1 B-MCKE
- B-MCK NC R203 2 1 B-MCK
- B-MCKB NC R204 2 1 B-MCKB
- B-MDQL0 NC RN21D 8 7 B-MDQL0
- B-MDQL1 NC RN21C 6 5 B-MDQL1
- B-MDQL2 NC RN21B 4 3 B-MDQL2
- B-MDQL3 NC RN21A 2 1 B-MDQL3
- B-MDQ07 NC RN22B 4 3 B-MDQ07
- B-MDQ11 NC RN22A 4 3 B-MDQ11
- B-MDQ3 NC RN22C 6 5 B-MDQ3
- B-MDQ5 NC RN22D 8 7 B-MDQ5
- B-MDQ5 NC R205 2 1 B-MDQL5
- B-MDQ3 NC RN23C 6 5 B-MDQL3
- B-MDQ6 NC RN23D 8 7 B-MDQL6
- B-MDQ7 NC RN23A 2 1 B-MDQL7
- B-MDQ1 NC RN23B 4 3 B-MDQL1
- B-MDQ02 NC RN24A 2 1 B-MDQ02
- B-MDQSL NC R206 2 1 B-MDQSL
- B-MDQSL NC R207 2 1 B-MDQSL
- B-MDQSUB NC R208 2 1 B-MDQSUB
- B-MDQSU NC R209 2 1 B-MDQSU
- B-MDML NC R210 2 1 B-MDMU
- B-MDQ06 NC RN24B 4 3 B-MDQ06
- B-MDQ04 NC RN24D 8 7 B-MDQ04
- B-MDQ00 NC RN24C 6 5 B-MDQ00
- B-MDQL1 NC RN23B 4 3 B-MDQL1




Unihan		Title : MSD8841	
MAIN BOARD		Engineer: Jeff Y Hsiao/Jerry Lo	
Size	Project Name	Rev 1.03a	
B	L2300	Date: Thursday, December 20, 2012	Sheet 10 of 23











<b>Unihan</b>		<b>Title :</b> COMPONENT
<b>MAIN BOARD</b>		<b>Engineer:</b> Jeff Y Hsiao/Jerry Lo
Size A	Project Name <b>L2300</b>	Rev 1.03a
Date: Thursday, December 20, 2012	Sheet 13 of 23	











Unihan


Title : SPDIF OUT

MAIN BOARD

Engineer: Jeff Y Hsiao/Jerry Lo

Size

A	Project Name	Rev
A	L2300	1.03a
Date: Thursday, December 20, 2012	Sheet 18 of 23	



**Unihan**

Title : **USB**

MAIN BOARD

Engineer: **Jeff Y Hsiao/Jerry Lo**

Size


Project Name


**L2300**

Rev  
1.03a

Date: **Thursday, December 20, 2012**

Sheet **19** of **23**





**Unihan**

Title : Ethernet Conn

MAIN BOARD

Engineer: Jeff Y Hsiao/Jerry Lo

Size


Project Name


L2300

Rev  
1.03a

Date: Thursday, December 20, 2012

Sheet 21 of 23





**Unihan**      Title : **IR\_ALS**  
 MAIN BOARD      Engineer: **Jeff Y Hsiao/Jerry Lo**  
 Size **A**      Project Name **L2300**      Rev **1.03a**  
 Date: **Thursday, December 20, 2012**      Sheet **23** of **23**

Subject: PCB Outline Drawing

Part No.: BK.01191.001


Rev.: 0


Doc. No.: 209-C002

Project Code: BK.01191.001

Page 1 of 1



Model Name: B191-001





# PRIMARY


# SECONDARY




DARFON	達方電子股份有限公司
CUSTOMER MODEL :	
CUSTOMER PART NO :	
DARFON Model Name : B191-001	
2012/12/03	REV. C
Prepared by David DC Wu	Reviewed by Yucheng Lin
	Approved by Jeff Shih

## PRIMARY

## SECONDARY



<b>DARFON</b>		達方電子股份有限公司	
CUSTOMER MODEL :		CUSTOMER PART NO :	
2012/12/03	REV. C	Reviewed by	Yucheng Lin
Prepared by David DC Wu	Approved by Jeff Shih		



DARFON

<b>DARFON</b>			達方電子股份有限公司	
			CUSTOMER MODEL : CUSTOMER PART NO : DARFON Model Name : B191-001	
2012/12/03	REV.	C	Reviewed by	<b>Yucheng Lin</b>
Prepared by	<b>David DC Wu</b>		Approved by	<b>Jeff Shih</b>